

140-017-22 / 140-017-42 / 140-017-72


140-018-22 / 140-018-42 / 140-018-72

140-012-22 / 140-012-42 / 140-012-72

140-013-72 / 140-013-42 / 140-013-22



Entnahme Lichtquelle zur Überprüfung / Removal of light source for verification



## Entnahme Betriebsgerät zur Überprüfung / Removal of control gear for verification

