





Entnahme Lichtquelle zur Überprüfung / Removal of light source for verification

|   |   |  |
|---|---|--|
|    |    |    |
| 1<br>remove the Hexagonal nut   | 2   | 3  |
|   |   |   |
| 4<br>remove the screw   | 5   | 6  |
|  |  |  |
| 1<br>remove the Hexagonal nut   | 2   | 3<br>remove the screw  |
|  |   |  |
| 4   |   |  |


Entnahme Betriebsgerät zur Überprüfung / Removal of control gear for verification




1  
remove the screw and switch



2  
remove the sleeve



3  
remove the wire from switch



4  
take apart the red wire from terminal



5  
remove the screw

