



### Entnahme Lichtquelle zur Überprüfung / Removal of light source for verification




1. release two screws




2. push the adapter




3. release the screw




4. Push out the adapter cover




5. remove the adapter cover



6. release the red and black wires




7. Push out the Lens



8. Push out the LED board

Entnahme Betriebsgerät zur Überprüfung / Removal of control gear for verification




1. release two screws



2. push the adapter



3. release the screw




4. Push out the adapter cover




5. remove the adapter cover




6. release the red and black wires



7. release the red and black wire



8. release the blue and brown wire



9. remove the driver